

# INSTALLATION INSTRUCTIONS

## 6903-50安裝說明

1. Using the Fixing Bracket as a template to select a proper position and mark center of mounting hole.  
以固定基座為基準選取預定安裝的位置，並在牆壁畫上預定鑽孔記號。
2. Using a 6mm drill-bit to drill a hole at marked position to 4cm depth. Insert the Plastic Anchor into the hole, and then fix Fixing Bracket to the wall with Wall Screw.  
當安裝在水泥牆時，使用6mm鑽頭，鑽孔深度4公分，嵌入塑膠塞，並使之齊平於牆面，將固定基座以螺絲鎖緊於牆上。
3. Screw the Hook Body to Fixing Bracket.  
將本體鎖進固定基座後，完成安裝程序。

6779  
SERIES:

PATENT NUMBER:  
專利號碼:



6903-50  
Hook

